

Handling & Storage of Reprorubber[®] Products

Products Include:

Reprorubber Thin Pour Includes Model Nos. 16116, 16135, 16137, 16300, 16301, 16302, 16309.

Reprorubber Quicksetting Putty Includes Model Nos. 16129, 16130, 16131.

Reprorubber Orange Includes Model Nos. 16305, 16306, 16307, 16309.

IMPORTANT INFORMATION

Please read the following information carefully. Failure to comply with these guidelines may result in reduced performance of this product and may void our warranty.

- Never store material above 80° F (27°C).
- Work with material only at room temperature 70° -75° F (21° - 24°C).
- Shelf life is approximately 18 months.
- Containers must be sealed tightly to avoid air contamination.
- Avoid cross-contamination of the original containers. For the Thin Pour product, you must not get blue liquid into the bottle of yellow liquid, or yellow liquid into the blue bottle of the blue liquid. For the Putty, never get gray putty in the blue putty jar. Do not interchange the lids. Any cross-contamination will result in the inactivation of the catalyst, ruining the product.
- If wearing gloves while using products, polyethylene or latex is recommended. **DO NOT USE POLYSULFIDE GLOVES!**



FLEXBAR MACHINE CORPORATION
250 Gibbs Road • Islandia, NY 11749
631-582-8440 • Fax 631-582-8487
1-800-879-7575 • Email: sales@flexbar.com